

COUNT AND INSPECT ALL PARTS CONFIRMING ALL WERE RECEIVED AND ARE IN GOOD CONDITION.

FOR ANY REPLACEMENT PARTS OR HARDWARE, AND/OR HELP WITH ASSEMBLY; CONTACT US.

PLEASE HAVE THE MODEL NUMBER AND/OR PART NUMBER
NEEDED AS SHOWN IN THE PACKAGING OR ASSEMBLY
MANUAL

SAFETY WARNINGS

- 1.FOLLOW THE INFORMATION ON THE WARNINGS APPEARING ON THE UPPER BUNK END STRUCTURE AND ON THE CARTON. DO NOT REMOVE WARNING LABEL FROM BED.
- 2. ALWAYS USE THE RECOMMENDED SIZE MATTRESS OR MATTRESS SUPPORT, OR BOTH, TO HELP PREVENT THE LIKELIHOOD OF ENTRAPMENT OR FALLS.
- 3.SURFACE OF MATTRESS MUST BE AT LEAST 5 INCHES BELLOW THE UPPER EDGE OF GUARDRAILS.
- 4. DO NOTALLOW CHILDREN UNDER 6 YEARS OF AGE TO USE THE UPPER BUNK.
- 5. PERIODICALLY CHECK AND ENSURE THAT THE GUARDRAIL, LADDER, AND OTHER COMPONENTS ARE IN THEIR PROPER POSITION, FREE FROM DAMAGE, AND **THAT ALL CONNECTORS ARE TIGHT.**
- 6. DO NOTALLOW HORSEPLAY ON OR UNDER THE BED AND PROHIBIT JUMPING ON THE BED.
- 7. ALWAYS USE THE LADDER FOR ENTERING ORLEAVING THE UPPER BUNK.
- 8. DO NOT USE SUBSTITUTE PARTS. CONTACT MANUFACTURER OR DEALER FOR REPLACEMENT PARTS.
- 9. USE OF A NIGHT LIGHT MAY PROVIDE ADDED SAFETY PRECAUTION FOR A CHILD USING THE UPPER BUNK.
- 10. ALWAYS USE GUARDRAILS ON BOTH LONG SIDES OF THE UPPER BUNK.
- 11.IF THE BUNK BED WILL BE PLACED NEXT TO AWALL, THE GUARDRAIL THAT RUNS THE FULL LENGTH OF THE BED SHOULD BE PLACED AGAINST THE WALL TO PREVENT ENTRAPMENT BETWEEN THE BED AND THE WALL.
- 12. PROHIBIT MORE THAN ONE PERSON ON THE UPPER BUNK.
- 13. THE USE OF WATER OR SLEEP FLOTATION MATTRESSES IS PROHIBITED.
- 14. KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

SIZE OF MATTRESS

USE ONLY MATTRESS MEETING THE FOLLOWING SPECIFICATIONS ON UPPER AND LOWER BUNKS:

STANDARD TWIN: 74" - 75" LONG AND 37 1/2" - 38 1/2" WIDE

STANDARD FULL: 74" - 75" LONG AND 52 1/2" - 53 1/2" WIDE

ENSURE THICKNESS OF MATTRESS DOES NOT EXCEED 9" ON UPPER OR LOWER BUNKS AND MATTRESS IS AT LEAST 5" BELOW UPPER EDGE OF GUARDRAILS.

<u>STRANGULATION HAZARD</u> - NEVER ATTACH ORHANG ITEMS TO ANY PART OF THE BUNK BED THAT ARE NOT DESIGNED FOR USE WITH THE BED: FOR EXAMPLE, BUT NOT LIMITED TO HOOKS, BELTS AND JUMP ROPES.

REPLACEMENT PARTS

REPLACEMENT PARTS, INCLUDING ADDITIONAL GUARDRAILS, MAY BE OBTAINED FROM ANY OF OUR DEALERS.



Bio Movel Certifies That Your Product is...

Environmentally Sustainable - Manufactured from 100% reforested pine wood from Brazil!

Environmentally Friendly - Consistently manufactured in accordance to local government laws and norms contributing to a cleaner, healthier environment!

Socially Responsible - Manufacturer conforms to all labor legislation without use of child labor. Offers employee benefits such as health, meals and transportation.

THANK YOU FOR YOUR PURCHASE!

TALL BUNK BED PANEL FULL





ATTENTION


- 1 Read and observe carefully all the assembly instructions before beginning assembly.
- 2 The assembly of the product must be done on a clean and flat surface. We suggest to use the packaging to cover the floor to avoid damages.
- 3 The screws must be tightened periodically.
- 4 Avoid contact with sharp objects.
- 5 Avoid banging pieces together.




Parts and hardware list for ASSEMBLY TALL BUNK BED FULL 10 05 (02)(25) 06 06 01 (04)04 (08)21 (10)**303** (05)03 (08) × 01) 04 04) 07 04 03 27x = + 2x spare 41x B+2x spare 8x **F** 02x ø3/8"x1 9/16" ø1/4"x4 1/4" ø3/8" 62x **J** G + 2x spare 08x 08x K + 1x spare + 2x spare 02x ø1/4"x3 7/8" ø1/8"x1 3/8" ø1/4" x 3 1/8" + 1x spare 12x P 08x **Q** 04x 50 ø1/4"x1 9/16" ø3/8"x3 1/8" ø1/4" ø1/4" x 2 5/16" Z + 2x spare + 2x spare 28x BG 60x **AA** 04x BH 02x ø1/8" x 5/8" ø1/4"x7/16" 2 3/4"










Pg 7/13



Pg 8/13

