



COUNT AND INSPECT ALL PARTS CONFIRMING ALL WERE RECEIVED AND ARE IN GOOD CONDITION.

FOR ANY REPLACEMENT PARTS OR HARDWARE, AND/OR HELP WITH ASSEMBLY; CONTACT US.

PLEASE HAVE THE MODEL NUMBER AND/OR PART NUMBER NEEDED AS SHOWN IN THE PACKAGING OR ASSEMBLY MANUAL

SAFETY WARNINGS

- 1.FOLLOW THE INFORMATION ON THE WARNINGS APPEARING ON THE UPPER BUNK END STRUCTURE AND ON THE CARTON. DO NOT REMOVE WARNING LABEL FROM BED.
2. ALWAYS USE THE RECOMMENDED SIZE MATTRESS OR MATTRESS SUPPORT, OR BOTH, TO HELP PREVENT THE LIKELIHOOD OF ENTRAPMENT OR FALLS.
- 3.SURFACE OF MATTRESS MUST BE AT LEAST 5 INCHES BELOW THE UPPER EDGE OF GUARDRAILS.
4. DO NOT ALLOW CHILDREN UNDER 6 YEARS OF AGE TO USE THE UPPER BUNK.
5. PERIODICALLY CHECK AND ENSURE THAT THE GUARDRAIL, LADDER, AND OTHER COMPONENTS ARE IN THEIR PROPER POSITION, FREE FROM DAMAGE, AND **THAT ALL CONNECTORS ARE TIGHT.**
6. DO NOT ALLOW HORSEPLAY ON OR UNDER THE BED AND PROHIBIT JUMPING ON THE BED.
7. ALWAYS USE THE LADDER FOR ENTERING OR LEAVING THE UPPER BUNK.
8. DO NOT USE SUBSTITUTE PARTS. CONTACT MANUFACTURER OR DEALER FOR REPLACEMENT PARTS.
9. USE OF A NIGHT LIGHT MAY PROVIDE ADDED SAFETY PRECAUTION FOR A CHILD USING THE UPPER BUNK.
10. ALWAYS USE GUARDRAILS ON BOTH LONG SIDES OF THE UPPER BUNK.
11. IF THE BUNK BED WILL BE PLACED NEXT TO A WALL, THE GUARDRAIL THAT RUNS THE FULL LENGTH OF THE BED SHOULD BE PLACED AGAINST THE WALL TO PREVENT ENTRAPMENT BETWEEN THE BED AND THE WALL.
12. PROHIBIT MORE THAN ONE PERSON ON THE UPPER BUNK.
13. THE USE OF WATER OR SLEEP FLOTATION MATTRESSES IS PROHIBITED.
14. KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

SIZE OF MATTRESS

USE ONLY MATTRESS MEETING THE FOLLOWING SPECIFICATIONS ON UPPER AND LOWER BUNKS:

STANDARD TWIN: 74" - 75" LONG AND 37 $\frac{1}{2}$ " - 38 $\frac{1}{2}$ " WIDE

STANDARD FULL: 74" - 75" LONG AND 52 $\frac{1}{2}$ " - 53 $\frac{1}{2}$ " WIDE

ENSURE THICKNESS OF MATTRESS DOES NOT EXCEED 9" ON UPPER OR LOWER BUNKS AND MATTRESS IS AT LEAST 5" BELOW UPPER EDGE OF GUARDRAILS.

STRANGULATION HAZARD - NEVER ATTACH OR HANG ITEMS TO ANY PART OF THE BUNK BED THAT ARE NOT DESIGNED FOR USE WITH THE BED: FOR EXAMPLE, BUT NOT LIMITED TO HOOKS, BELTS AND JUMP ROPES.

REPLACEMENT PARTS

REPLACEMENT PARTS, INCLUDING ADDITIONAL GUARDRAILS, MAY BE OBTAINED FROM ANY OF OUR DEALERS.



FURNITURE FOR A HEALTHIER HOME

Bio Movel Certifies That Your Product is...

Environmentally Sustainable - Manufactured from 100% reforested pine wood from Brazil!

Environmentally Friendly - Consistently manufactured in accordance to local government laws and norms contributing to a cleaner, healthier environment!

Socially Responsible - Manufacturer conforms to all labor legislation without use of child labor. Offers employee benefits such as health, meals and transportation.


THANK YOU FOR YOUR PURCHASE!

HIGH LOFT BED PANEL TWIN


















ATTENTION

- 1 - Read and observe carefully all the assembly instructions before beginning assembly.
- 2 - The assembly of the product must be done on a clean and flat surface. We suggest to use the packaging to cover the floor to avoid damages.
- 3 - The screws must be tightened periodically.
- 4 - Avoid contact with sharp objects.
- 5 - Avoid banging pieces together.




Parts and hardware list for **ASSEMBLY HIGH LOFT BED TWIN**




A + 2x spare 53x  $\varnothing 3/8" \times 1 9/16"$	B + 2x spare 27x  $\varnothing 1/4" \times 4 1/4"$	E + 2x spare 8x  $\varnothing 3/8"$	F 02x 
G + 2x spare 04x  $\varnothing 1/4" \times 3 7/8"$	I + 2x spare 34x  $\varnothing 1/8" \times 1 3/8"$	J 02x 	K + 1x spare 02x  $\varnothing 1/4" \times 3 1/8"$
L + 1x spare 01x  $\varnothing 1/4"$	N + 2x spare 10x  $\varnothing 1/4" \times 2 5/16"$	Z + 2x spare 18x  $\varnothing 1/8" \times 5/8"$	AA + 2x spare 28x  $\varnothing 1/4" \times 7/16"$
BG 02x 	BH 02x  $2 3/4"$		

Step 01 -


ASSEMBLY INSTRUCTIONS




Step 02 -









Step 03 -








Step 04 -




B  03x	AA  03x	J  01x	Z  04x
		F  01x	G  01x

Step 05 -





B  03x	AA  03x
F  01x	G  01x

Step 06 -



Step 07 -



03x




AA

03x



01x




Z

04x



F


01x







G


01x

Step 08 -




B  14x	AA  14x	F  01x	Z  04x
--	---	---	--




Step 09 -




Step 10 -










Step 11 -




LADDER LEFT



LADDER RIGHT

A	 05x	B	 01x	AA	 02x	F	 02x
K	 02x	L	 01x	Z	 02x		

Step 12 -



E		08x	I		06x
---	--	-----	---	--	-----