


---

# CHANDELIER

## ASSEMBLY INSTRUCTIONS

REMOVE ALL PARTS FROM PACKAGE, BE CAREFUL NOT  
TO DAMAGE ANY COMPONENTS.




---


PROFESSIONAL INSTALLATION RECOMMENDED

## CHANDELIER

REMOVE ALL PARTS FROM PACKAGE, BE CAREFUL NOT TO DAMAGE ANY COMPONENTS.



1. Measure area and determine desired hanging height.
2. Product comes with three (3) 12", one (1) 8" and one (1) 4" hard stems [A] for adjustable hanging height. Determine the stems you will use to achieve desired height. (Threads are removable from the stems and thread removal may make it easier to thread wire).
3. Thread wire [E] from socket part [B] through first stem [A]. Continue to add stems, threading the wire and screwing each stem together. Repeat as necessary to achieve desired hanging height.
4. Detach mounting plate [C] from canopy [D].
5. Mounting plate [C] will attach to ceiling junction box.
6. Install light to ceiling. We recommend installation by a qualified electrical professional. Canopy nuts [E] are used to tighten light to ceiling.
7. Unscrew socket cover screw [G] from socket cover [H] and lift socket cover [H]. Install bulb 40W max.
8. Slide socket [B] into glass shade [F]. Metal socket top will be inside glass shade [F].
9. Lower socket cover [H] over top of glass shade [F]. Tighten by using socket cover screw [G].



Note: Turn off switch before replacing the bulb. Make sure the bulb has sufficient time to cool down.  
Do not subject the lamp to any shock while lit as shattering of glass shade may result.