

We love the outdoor furniture you chose! To keep it looking like new, please review these tips. Sun, water, and dirt can lead to fading and damage. Outdoor furniture should be cleaned at the start of each season (four times a year).

Be sure to consult your owner's manual for more detailed instructions, as specifications may vary across manufacturers. We recommend keeping a copy of this document for future reference.


## Cleaning

Different materials require different cleaning methods, which are outlined below. **Don't forget to remove the cushions first.**




### Upholstery & Fabric

Most outdoor fabric, such as cushion covers, can be machine-washed on the gentle cycle. Once clean, let them dry outside.




### Wood

Clean with soapy water and then rinse with cold water. Make sure you let it fully dry before using it again.



### Metal

To clean, use dish soap mixed with water and wipe the surfaces with a soft rag. To prevent rust, cover your furniture during periods of rain or dampness. Make sure your piece is covered entirely to prevent damage to the base or feet.



### Wicker

Simply spray your wicker furniture with a hose. If it is extra dirty, mix mild soap with water and use a sponge before rinsing with cold water.

## Storing for Bad Weather

Here's what to do when the forecast isn't ideal.

- **Rainy Days:** Be proactive and bring all of your cushions inside. They aren't built to weather storms.
- **Winterization:** Store your furniture inside during the winter. If this isn't possible, make sure it is covered.