


**10'x12' HARDTOP GAZEBO WITH  
DOUBLE ROOF**

**ASSEMBLY MANUAL**






1. Two or more people are required for assembly.



5. Use the hex keys in the box.



2. You will need one or more stepladders.



6. Please use a Phillips screwdriver.



3. Wearing protective gloves is recommended.



7. Do not fully tighten screws prior to complete assembly.




4. You may need a safety hat.



8. For ease of construction, you may need to use a drill.

## 10x12' ANCHOR BLUEPRINT





A (x4)



J1 (x4)




B (x2)



J2 (x4)




B1 (x2)



K (x1)




B2 (x2)



K1 (x1)



C (x2)



L (x4)



C1 (x2)



M (x4)



C2 (x2)



N (x4)



D (x2)



D1 (x2)




D2 (x2)




E (x2)



E1 (x2)



E2 (x2)



F (x4)



G (x4)



H (x4)






H1 (x4)













H2 (x1)

ITEM	DESCRIPTION	QTY
A	Pole	4
B	Beam	2
B1	Joint Bar	2
B2	Sidewall Track	2
C	Beam	2
C1	Jointer Bar	2
C2	Sidewall Track	2
D	Beam	2
D1	Jointer Bar	2
D2	Sidewall Track	2
E	Beam	2
E1	Jointer Bar	2
E2	Sidewall Track	2
F	Union Bar	4
G	Corner Cover	4
H	Joint Cover	4
H1	Joint Cover	4
H2	Silicone Rubber	1
J1	Corner Solidifying Bar	4
J2	Corner Solidifying Bar	4
K	Inside Roof Connector	1
K1	Outside Roof Connector	1
L	Base	4
M	Corner roof bar	4
N	roof bar	4




ITEM	DESCRIPTION	QTY
P	Finishing Bar	2
P1	Net Frame	2
Q	Finishing Bar	2
Q1	Net Frame	2
Q2	Net Frame	2
R	Finishing End	8
S	Spacer	96
T1	Finishing Bar	2
T2	Finishing Bar	2
U0	Solidifying Bar	2
U	Solidifying Bar	2
U3	Iron Angle	4
U4	Iron Angle	4
V1	Roof Panel	2
V2	Roof Panel	2
V3	Roof Panel	2
V4	Roof Panel	2
V5	Roof Panel	2
V6	Roof Panel	2
W3	Roof Panel	2
W4	Roof Panel	2
W1	Roof Panel	2
W2	Roof Panel	2
W5	Roof Panel	2
W6	Roof Panel	2
X4	Roof Panel	2
X5	Roof Panel	2




1# (x218+4)



2# (x16+2)



3# (x16+2)



4# (x104)



5# (x64+3)



6# (x8+1)




7# (x28+2)




9# (x24+2)



10# (x4+1)




11# (x8+1)





ITEM	DESCRIPTION	QTY
X1	Roof Panel	2
X2	Roof Panel	2
X7	Roof Panel	2
X8	Roof Panel	2
X3	Roof Panel	2
X6	Roof Panel	2
Y1 & Y2	Mosquito Sidewall	4
Y5 & Y6	Solid Sidewall	4
Yb	Strap	4
Z	Metal Bracket	56
Z1	Metal Bracket	4
Z2	Metal Bracket	4
Z3	Metal Bracket	4
Z4	Metal Bracket	4
1#	Screws	218+4
2#	Screws	16+2
3#	Screws	16+2
4#	Hook	104
5#	Screws	64+3
6#	Screws	8+1
7#	Screws	28+2
9#	Screws	24+2
10#	Screws	4+1
11#	Screws	8+1
	Allen key/ Wrench	3

## Parts Required:





## Step 1:

Set up poles (Part A) with stand plates (Part L) using screws 1# as shown in diagram.




## Parts Required:




## Step 2:

Connect (Part C) and (Part B) into one beam using union bar (Part F) with screws 1#.




Connect Part E and Part D into one beam using union bar (Part F) with screws 1# as shown in diagram.


# Parts Required:



## Step 3:




Connect parts (E2&D2) to the finished beam (part E& part D) using screws 1# as shown in diagram.  
Replicate the same steps for parts (C2 & B2), attaching them to the finished beam (C & B) using screws 1#.




Attach parts (E1& D1) to finished beam (E & D) using screws 1#.  
Attach parts (C1 & B1) to finished beam (C & B) using screws 1#.



## Parts Required:






2#  
x16



3#  
x16

### Step 4:

Use screws (2# & 3#) to connect poles and beams together as shown in diagram.



## Parts Required:




J1 (x4)



J2 (x4)




1#  
x32



## Step 5:

Affix the frame with corner solidifying bars (Parts J1 & J2) using screws 1# as shown in diagram.



## Parts Required:



G x4




H x4




1#  
x4



9#  
x24



①





②

## Step 6:

Finish connecting beams using corner covers (Part G) and screws 9# as shown in diagram.

Affix middle beams using joint cover (Part H) and screws 9# and 1# as shown in diagram.








4#  
x104



H1 (x4)




After finishing hooks into tracks,  
then put H1 to lock them.




## Step 7:





- ① Put 6 hooks to each slot of  
sidewall track (part C2&Part B2)



- ② Put 7 hooks to each slot of  
sidewall track (part E2&Part D2)




## Parts Required:




## Reminder:

with silicone rubber to seal  
after finishing the assembly  
it will be better for no water  
leaking in heavy rain.







## Parts Required:





## Step 8: Set up roof frame




Attach corner roof bar(Part M) to main frame using screw 1# as shown in diagram

Attach finishing bar (Part P&Q) with finish end (Part R) using screws 1# to corner roof bar (Part M) as shown in diagram.






## Parts Required:




1#  
x12

Step 9:



Attach roof bar (Part N)  
to main frame using screw 1#  
as shown in diagram.


Parts Required:




K1 (x1)



1#  
x2



**Step 10:** Connect outside roof connctor (Part K1)to inside roof (Part K)using screw 1# as shown in diagram.





Parts Required:

V1 (x2)

V2 (x2)

V3 (x2)

V4 (x2)

V5 (x2)


V6 (x2)

Z1 (x4)




Z (x8)

Z2 (x4)


Step 11: Cover metal bracket (Part Z,Z1,Z2) to roof panels as shown in diagram.




# Parts Required:




V2



V4





V6




## Step 12:

Push the roof panels (Part v1,v2,v3,v4,v5,v6) to upper roof as shown in diagram.

Attach finishing bars (Part T1&T2) to upper roof with finish end (Part R) using screws 1#as shown in diagram.




# Parts Required:



U0 (x4)




U3 (x4)



U4 (x4)





1#  
x24





## Step 13:

Affix solidifying bars to roof corner bar using iron angle (Part U3) and screw 1# as shown in diagram.

Affix solidifying bars (Part U0&U) together to roof bar using iron angle (Part U4) and screws 1# as shown in diagram.




Parts Required:






Step 14:

Cover metal bracket (Part Z,Z3,Z4) to roof panels as shown in diagram.




Parts Required:




Overall roof assembly:

Please put the panels on the frame anti-clockwisely



**Tips:** For fastening roof panels (Part W3 and Part X4) easily, please glue Part S onto Panel W3 and Part X4 by adhesive tape in advance to avoid Part S sliding down during assembly..





# Parts Required:

S x104

5# x64






6# x8

7# x28

10# x4

**Step 15:** Affix roof panels using screws and spacers (Part S) as shown in diagram.


**Attention:**  
Put on one roof panel and fasten it accordingly before attaching second roof panel.




## Parts Required:



P1 (x2)



Q1 (x2)



Q2 (x2)






1#  
x4




11#  
x8

### Step 16:




### Perspective:




Attach net frames (Part P1,Q1&Q2)  
to finishing bars (Part P &Q)  
using screws 1#&11# as shown in diagram.




## Parts Required:




Y1(x2)




Y2(x2)




Y5(x2)



Y6(x2)





4#




Y1&Y2

Y5&Y6

**Step 17:**  
Hang up mosquito sidewalls and solid sidewalls as shown in diagram.











Parts Required:



Yb X4

Step 18: When you close the curtain, please refer to below steps to fix with poles as shown in diagram.



In the end, Check all screws are fixed tightly before using.