



# Assembly Instructions




*Please visit our website for the most current instructions, assembly tips, report damage, or request parts.*

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product .




- VIII. Concealed hinges are three-way adjustable.



Horizontal  
by screw adjustment




In-and-Out  
by loosening the hinge-arm  
mounting screw or via cam  
adjustment

























Vertical  
Via slots in the mounting  
plate or via cam adjustment

# Parts List



# Hardware List



A		Ø8x30mm	Wooden dowel	19 pcs
B		Ø6x35mm	Cam bolt	14 pcs
C		Ø15x11mm	Cam lock	14 pcs
D		Ø30mm	Sticker	14 pcs
E		M 4	Hex Key	1 pcs
F		Ø6x50mm	Screw	8 pcs
G		Ø6x12mm	Bolt	18 pcs
H			Plastic wedge	9 pcs
J			Shelf support pin	8 pcs
K			Europe hinge	4 pcs
L		Ø3.5x14mm	Screw	24 pcs
M			Handle	2 pcs
N		Ø4x22mm	Handle Bolt	6 pcs
P		Ø6x30mm	Screw	2 pcs
Q		Ø4x32mm	Screw	4 pcs
R			Plastic wedge	8 pcs
S		Ø3x17mm	Screw	8 pcs
T		Ø4x15mm	Screw	4 pcs
U			L shape bracket	2 pcs
V		F18V66L	Fireplace Insert	1 pc
W			Glue tube	1 pc



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Secure cam bolt (B) into part (1), insert wooden dowel (A) into part (1) ,then using cam lock (C) attach cam bolt (B) ,wooden dowel (A) into part (9) to part (1) with Philips head screwdriver as per diagram.

## Step 2





Insert wooden dowel (A) into parts (3,4,5) as per diagram.

## Step 3



Insert wooden dowel (A) into part (6) ,then using cam bolt (B) secure parts (7,8) with Philips head screwdriver as per diagram.


## Step 4



Using cam lock(C) secure part (7) to part (5) ,part (8) to part (6) with Philips head screwdriver as per diagram.





## Step 5





Using screw (Q) attach part (10) into parts (7,8) with Philips head screwdriver as per diagram.

## Step 6




Using cam lock(C) secure parts (3,5,6) to part (1) with Philips head screwdriver as per diagram.

# Step 7




Using cam lock(C) secure part (4) to part (1) with Philips head screwdriver as per diagram.

## Step 8




Put part (11) as per diagram.

## Step 9




Using screw (P) attach part (16) into part(2) with hex key (E) as per diagram.

## Step 10




Using screw (F) attach part (2) into parts (3,4,5,6) with hex key (E) as per diagram.

# Step 11



Using bolt (G) secure plastic wedge (H) to parts (13,14,15) with hex key (E) as per diagram.


## Step 12



Using bolt (G) secure plastic wedge (H) in parts (13,14) to part (15) with hex key (E) as per diagram.






# Step 13




Using bolt (G) secure plastic wedge (H) in parts (13,14,15) to part (2) with hex key (E) as per diagram.

## Step 14




Using screw (S) secure plastic wedge (R) to back panel with Philips head screwdriver as per diagram.

## Step 15




Place sticker (D) cover the holes as per diagram .

## Step 16



Insert shelf support pin (J) into parts (3,4,5,6) as per diagram.


## Step 17



Put part (12) as per diagram.


## Step 18

x 2





Using handle bolt (N) attach handle (M) into parts (17) ,and using screw (L) attach Europe hinge (K) into part (17)with Philips head screwdriver as per diagram.

## Step 19



Using screw (L) attach Europe hinge (K) into part (3) with Philips head screwdriver as per diagram.


## Step 20



Using screw (L) attach Europe hinge (K) into part (4) with Philips head screwdriver as per diagram.





## Step 21




Put Fireplace insert (V) as per diagram.

## Step 22




Using screw (T) attach L shape bracket (U) into part (5) with Philips head screwdriver as per diagram.

## Step 23




Using screw (T) attach L shape bracket (U) into part (6) with Philips head screwdriver as per diagram.

## Step 24



If necessary, adjust the Floor Levelers at the bottom to level the unit.

## Step 25



## Final Assembly