



# Assembly Instructions




*Please visit our website for the most current instructions, assembly tips, report damage, or request parts.*

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.
















- VIII. Drill may be needed for securing product to wall.

# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	12 pcs
B		Ø6x35mm	Cam bolt	8 pcs
C		Ø15x11mm	Cam lock	8 pcs
D		Ø30mm	Sticker	8 pcs
E		Ø6x50mm	Screw	6 pcs
F		M 4	Hex Key	1 pc
G		Ø6x15mm	Bolt	8 pcs
H		Ø6x15mm	Bolt	8 pcs
J			L shape bracket	4 pcs
K			Plastic wedge	6 pcs
L		Ø3x17mm	Screw	6 pcs
M			Glue tube	1 pc



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Using cam bolt (B) secure part (1) with Philips head screwdriver .

## Step 2




Attach cam bolts (B) to parts (4,5,6,7) using Phillip's head screwdriver. Then attach bracket (J) to parts (4,5,6,7) using bolts(G) and hex key (F) as per diagram.

## Step 3



Using bolt (H) secure part (8) to part (4) ,then secure to part (5) as per diagram.


## Step 4



Using bolt (H) secure part (8) to part (6) ,then secure to part (7) as per diagram.




## Step 5




Insert wooden dowel (A) to part (3,11) as per diagram.

## Step 6





Attach part (9) to part (2) using screw (E) and hex key (F) .

## Step 7





Using screw (E) secure parts (2) to part parts (3,11) using hex key (F) .

## Step 8




Using cam lock (C) connect part (2) to parts (6,7) as per diagram.

## Step 9






Using cam lock (C) connect part (2) to parts (4,5) as per diagram.

## Step 10






Insert part (10) to parts (2,5,7) as per diagram.

# Step 11



Put part (1) to parts (3,4,5,6,7,11) ,and using bolt (G) secure L shape bracket (J) with hex key (F) as per diagram .


## Step 12



Using screw (L) secure plastic wedge (K) to part (10) with Philips head screwdriver as per diagram.




## Step 13



Place sticker (D) cover the holes as per diagram.

## Step 14



Final Assembly