



# Assembly Instructions




# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.




- VIII. Drill may be needed for securing product to wall.


- IX. Concealed hinges are three-way adjustable.



Horizontal  
by screw adjustment




In-and-Out  
by loosening the hinge-arm  
mounting screw or via cam  
adjustment






















Vertical  
Via slots in the mounting  
plate or via cam adjustment

# Parts List



# Hardware List


|   |   |           |                           |        |
|---|---|-----------|---------------------------|--------|
| A |    | Ø8x30mm   | Wooden dowel              | 32 pcs |
| B |    | Ø6x35mm   | Cam bolt                  | 26 pcs |
| C |    | Ø15x11mm  | Cam lock                  | 26 pcs |
| D |    | Ø30mm     | Sticker                   | 26 pcs |
| E |    | Ø6x50mm   | Screw                     | 4 pcs  |
| F |    |           | Plastic wedge             | 16 pcs |
| G |    | Ø3x17mm   | Screw                     | 16 pcs |
| H |    |           | Handle                    | 2 pcs  |
| J |    | Ø4x25mm   | Bolt                      | 4 pcs  |
| K |    |           | Europe Hinge              | 6 pcs  |
| L |    | Ø3.5x14mm | Screw                     | 36 pcs |
| M |   |           | Door stopper              | 1 pc   |
| N |  | Ø3x14mm   | Screw(Black)              | 2 pcs  |
| P |  |           | L shape shelf support pin | 12 pcs |
| Q |  | 4mm       | Hex Key                   | 1 pc   |
| R |  |           | Velcro strap              | 2 pcs  |
| S |  | Ø4x25mm   | Screw                     | 2 pcs  |
| T |  |           | Nut                       | 2 pcs  |
| U |  | Ø4x12mm   | Screw                     | 2 pcs  |
| V |  |           | Glue tube                 | 1 pc   |



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Insert wooden dowel (A) into parts (3,4,9), then secure cam bolt (B) into parts (3,4) with Philips head screwdriver as per diagram.

## Step 2




Secure cam bolt (B) into parts (1,2), then using screw (Black) (N) attach door stopper (M) to part (1) with Philips head screwdriver as per diagram.

## Step 3




Insert wooden dowel (A) into parts (10,11,12), then secure cam bolt (B) into part (12) with Philips head screwdriver as per diagram.

## Step 4





x 2



Using cam lock(C) secure parts (12) to part (10) with Philips head screwdriver as per diagram.





## Step 5





Using cam lock(C) secure parts (12) to parts (11) with Philips head screwdriver as per diagram.

## Step 6




Using cam lock(C) secure parts (3,4) to part (9) with Philips head screwdriver as per diagram.

## Step 7




Using cam lock(C) secure part (1) to parts (3,4) with Philips head screwdriver as per diagram.

## Step 8




Put part (5) as per diagram.

## Step 9




Put parts (5,6) as per diagram.

## Step 10





Using screw (E) attach part (2) into parts (3,4) with hex key (Q) as per diagram.

## Step 11



Using screw (G) secure plastic wedge (F) to part (5) with Philips head screwdriver as per diagram.


## Step 12



Using cam lock(C) secure parts (10,11) to part (2) with Philips head screwdriver as per diagram.




## Step 13




Place sticker (D) cover the holes as per diagram .

## Step 14



Insert L shape shelf support pin (P) into parts (3,4) as per diagram.


## Step 15



Put parts (7,8) into unit as per diagram.


Tilt and rest the adjustable shelves(7,8) onto the shelf support pins .

## Step 16




The reverse side of part (8) also can be used as shelf .Put part (8) into the unit as per diagram .

## Step 17




Using screw (L) attach Europe hinge (K) ,bolt (J) attach handle (H) into parts (13,14) with Philips head screwdriver as per diagram.

## Step 18




Using screw (L) attach Europe hinge (K) into part (3) with Philips head screwdriver as per diagram.

## Step 19



Using screw (L) attach Europe hinge (K) into part (4) with Philips head screwdriver as per diagram. Open and close the doors .If necessary ,adjust the screws for a good fit .

## Step 20




Using screw (U) attach Velcro strap (R) into part (1) with Philips head screwdriver as per diagram.




## Step 21

### WARNING




Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Wall



Using screw (S) attach Velcro strap (R) into Nut (T) to wall with Philips head screwdriver as per diagram.

## Step 22



Final Assembly