


Assembly Instructions




Please visit our website for the most current instructions, assembly tips, report damage, or request parts.


(E)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.






















- VIII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	30 pcs
B		Ø15x11mm	Cam lock	21 pcs
C		Ø6x35mm	Cam bolt	21 pcs
D		Ø30mm	Sticker	21 pcs
E		Ø6x50mm	Bolt	10 pcs
F		M 4	Hex Key	1 pc
G		Ø6x12mm	Bolt	14 pcs
J		56x27x27mm	Connector	7 pcs
K		Ø4x22mm	Bolt	4 pcs
L			Handle	2 pcs
M		Ø3x17mm	Screw	12 pcs
N			Plastic wedge	12 pcs
P			Shelf support pin	12 pcs
Q			Pulley	4 pcs
R		Ø6x12mm	Bolt	8 pcs
S			Plate	4 pcs
T		Ø4x12mm	Screw	8 pcs
U			Glue tube	1 pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert wooden dowel (A) to part (8) ,using cam bolt (C) secure part (1) with Philips head screwdriver as per diagram.

Step 2





Insert wooden dowel (A) to parts (10,11,12,13) .

Step 3





Insert wooden dowel (A) to parts (20,21). using cam bolt (C) secure parts (7,9,20,21) with Philips head screwdriver as per diagram.

Step 4





Using cam lock (B) secure parts (11,13) to parts (20,21) with Philips head screwdriver as per diagram.

Step 5




Using cam lock (B) secure parts (7,9) to parts (10,12) with Philips head screwdriver as per diagram.

Step 6




Using cam lock (B) secure part (8) to parts (7,9,20,21) with Philips head screwdriver as per diagram.

Step 7




Using bolt (E) secure part (2) to part (6) with hex key (F) as per diagram.

Step 8




Using bolt (E) secure part (2) to parts (10,11,12,13) with hex key (F) as per diagram.

Step 9




Using bolt (G) secure connector (J) into parts (3,4,5) with hex key (F) as per diagram.

Step 10




Using bolt (G) secure connector (J) into parts (3,4,5) with hex key (F) as per diagram.

Step 11




Using bolt (G) secure connector (J) into parts (2,3,4,5) with hex key (F) as per diagram.

Step 12




Using bolt (K) secure handle (L) into parts (18,19),and using bolt (R) secure pulley (Q) to parts (18,19) with Philips head screwdriver as per diagram.

Step 13




Put parts (18,19) as per diagram.

Step 14





Using screw (T) secure plate (S) into parts (2,18,19) with Philips head screwdriver as per diagram.

Step 15






Put parts (16,17) into parts (2,10,11,12,13) as per diagram.

Step 16




Using cam lock (B) secure part (1) into parts (10,11,12,13) with Philips head screwdriver as per diagram.

Step 17




Using screw (M) secure plastic wedge (N) with Philips head screwdriver as per diagram.

Step 18






Place sticker (D) cover the holes as per diagram.

Step 19




Insert shelf support pin (P) into parts (10,11,12,13) ,then put part (15) into parts (10,11,12,13) as per diagram.

Step 20



Insert shelf support pin (P) into parts (11,13) ,then put part (14) into parts (11,13) as per diagram.

Step 21



Final Assembly