

ASSEMBLY INSTRUCTIONS

ASSEMBLY

2 HOURS


2 -Person Assembly

Tools Required (Not Provided):


REQUIREMENTS

Assembly Time


(Approximate)



Phillips Screwdriver



Flat Head Screwdriver



Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product.

Contact our customer service department in case there are any missing or damage parts or hardware.

Replacement parts are normally shipped within 2 or 3 days.

We appreciate your business!

ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are complete before you start assembly.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

SAFETY PRECAUTION:

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY:

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Please check all of the parts and quantities are included before assembly. Contact customer service for missing parts.
4. Identify all of the parts, hardware and quantities required for each step.
5. During assembly, do not over-tighten any fittings as this may cause damage.
6. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
7. Always place the product on a flat surface.
8. Do not sit or stand on the partially assembled product; only use the product for which it is intended.


CARE AND MAINTENANCE

CLEANING - Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.


FITTINGS - Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.

This product is for indoor and household-use only - not for commercial use.

ASSEMBLY INSTRUCTIONS



















Hardware List

ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
A	Cam-bolt	 6*35mm	22 pcs	H	Screw	 2.5*10mm	34 pcs
B	Cam-lock	 15*10mm	22 pcs	I	Hinge	 40mm	4 pcs
C	Screw	 4*40mm	9 pcs	J	Handle Bolt	 4*14mm	2 pcs
D	Screw	 3*14mm	4 pcs	K	Handle		2 pcs
E	Screw	 3*12mm	22 pcs	L	Wood Dowel	 5.8*30mm	36 pcs
F	Screw	 5*70mm	4 pcs	M	Magnetic Catch		2 pcs
G	Magnetic Bar	 35*12*1mm	2 pcs				


ASSEMBLY INSTRUCTIONS

Parts List


ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
1	Top Panel		1 pc	9	Middle Shelf		1 pc
2	Left Side Panel		1 pc	10	Left Shelf		1 pc
3	Right Side Panel		1 pc	11	Right Shelf		1 pc
4	Bottom Panel		1 pc	12	Left Door		1 pc
5	Bottom Connect Bar		2 pcs	13	Right Door		1 pc
6	Top Connect Bar		1 pc	14	X Panel		2 pcs
7	Left Divide Panel		1 pc	15	Middle Back Panel		1 pc
8	Right Divide Panel		1 pc	16	Side Back Panel		2 pcs

ASSEMBLY INSTRUCTIONS


Parts List Assembly Overview




Instructions For Fastening CAM-BOLT AND CAM-LOCK



Attach the Cam-bolt to the specific pre-drilled holes on the panel. Use a Phillips Screwdriver to tighten Cam-bolt vertically until shoulder is flushed (on the same level) with panel. Do not over-tighten or under-tighten.






Align the arrow of the Cam-lock to the Cam-bolt head and insert the Cam-lock.




Use a Flat Screwdriver to turn the Cam-lock clockwise one half a turn so it locks onto the head of the Cam-lock. Turn only until it is snug. Over-tightening could damage Cam-lock or/and Cam-bolt.

STEP 1




C		6 pcs
L		4 pcs





DO NOT USE POWER TOOLS

1. Attach Bottom Connect Bar (5) to Bottom Panel (4) by using Screw (C) and Wood Dowel (L).

STEP 2




A		4 pcs
---	---	-------



DO NOT USE POWER TOOLS


1. Attach Cam-bolt (A) to the specific pre-drilled holes on Left and Right Divide Panel (7 & 8) as shown.

STEP 3




1. Insert Wooden Dowel (L) to Middle Shelf (9).
2. Attach Left and Right Divide Panel (7 & 8) to Middle Shelf (9) via Cam-bolts and Wood Dowels, respectively.
3. Insert Cam-lock (B) then turn clockwise to secure Cam-bolt in place.

STEP 4




1. Attach Cam-bolt (A) to the specific pre-drilled holes on Bottom Panel (4).

STEP 5




A		2 pcs
B		4 pcs
L		4 pcs




1. Insert Wooden Dowel (L) to the Divide Panels (7 & 8) of the assembly unit from Step 3 and attach it to the assembly unit from Step 4 via Cam-bolts and Wood Dowels, respectively.
2. Insert Cam-lock (B) then turn clockwise to secure Cam-bolt on Bottom Panel (4).
3. Attach Cam-bolt (A) to the Divide Panels (7 & 8)).

STEP 6

A		4 pcs
---	--	-------




DO NOT USE POWER TOOLS




1. Attach Cam-bolt (A) to Left and Right Side Panel (2 & 3).

STEP 7




1. Attach Magnetic Catch (M) to Left Shelf (10) by using screw (D).
2. Attach Left Shelf (10) to Left Divide Panel by using Wood Dowel (L) as shown.
3. Insert Cam-lock (B) then turn clockwise to secure Cam-bolt in place.



STEP 8



1. Attach Left Side Panel (2) by using Wood Dowel (L) and Screw (F).
2. Attach Top Connect Bar (6) to Left Side Panel (2) by using Wooden Dowel (L).
3. Insert Cam-lock (B) then turn clockwise to secure Cam-bolt in place.


STEP 9





B		2 pcs
C		2 pcs

1. Attach Magnetic Catch (M) to Right Shelf (11) by using Screw (D).


STEP 10




B		1 pc
L		2 pcs

1. Attach Right Shelf (11) by using Wood Dowel (L) as shown.
2. Insert Cam-lock (B) then turn clockwise to secure Cam-bolt in place.


STEP 11



B		2 pcs
F		2 pcs
L		5 pcs




DO NOT USE POWER TOOLS




1. Attach Right Side Panel (3) by using Wood Dowel (L) and Screw (F).
2. Insert Cam-lock (B) then turn clockwise to secure Cam-bolt in place.

STEP 12




1. Attach Cam-bolt (A) to the specific pre-drilled holes on Top Panel (1) as shown.

STEP 13




1. Attach Top Panel (1) by using Wood Dowel (L) and Screw (C).
2. Insert Cam-lock (B) then turn clockwise to secure Cam-bolt in place.

STEP 14




1. Attach Back Panel (15 & 16) by using Screw (H).


STEP 15




1. Attach Hinge (I) to Left Door (12) and Right Door (13) by using Screw (E).
2. Attach Handle (K) to Door (12 & 13) by using Handle Bolt (J).
3. Attach Magnetic Bar (G) to Door (12 & 13) by using Screw (E).

STEP 16




E	 3*12mm	12 pcs
---	--	--------




1. Install Left and Right Door (12 & 13) by using Screw (E).

STEP 17



1. Assemble X-Panel (14) as shown.

STEP 18



1. Insert assembled X-Panels.