







Storage Bed

This product is shipped in
3 cartons




Required Tools	Optional Tools
<p data-bbox="82 1816 220 1843">Screwdrivers</p>   <p data-bbox="573 1816 716 1843">Phillips Head</p>  <p data-bbox="573 1900 678 1927">Flat Head</p>  <p data-bbox="427 1984 524 2011">Hammer</p>	<p data-bbox="748 1816 1062 1885">Using a power screwdriver will speed up assembly.</p>  <p data-bbox="748 1913 849 1940">Caution</p> <p data-bbox="748 1940 1208 2032">Do not over tighten any screw. The last few turns of each screw should be done very slowly or by hand.</p>

Hardware Identification


Bed Hardware



JRN Nut
(24)



JCB Connector
(24)
bronze (cherry / espresso)
Chrome (white / maple)
black




T Spacer
(24)



Drawer Slide Screw
(90)




Allen Key
(1)




Drawer Bottom
Stabilizer (6)

Drawer Slides for Bed




LEFT Slide (6)




RIGHT Slide (6)

Drawer Hardware



1 LEFT Drawer Slide per Drawer (Total = 6)



1 RIGHT Drawer Slide per Drawer (Total = 6)


4 per drawer



#8 - 1 1/2" Hi Lo Screws
(24)




12mm Zinc Cam
(24)



34mm Black Twister Dowel
(24)

5 per drawer




3/4" Nail
(30)

8 per drawer



Drawer Slide Screw
(48)

Bed Parts



(B1)

Outer Gables (2)
black
cherry
espresso
maple
white

(B2)

Inner Gables (2)
black
cherry
espresso
Maple
white

(B3)

Upper Stabilizer (2)
black
cherry
espresso
maple
white

(B4)

Lower Stabilizer (2)
black
cherry
espresso
maple
white

(B5)


Plywood Slats (9)

(B6)

Metal U-channel with
Blocks (2)


STEP 1 Estimated Time: 10 minutes

Attach metal U-channels to each outer gable using drawer slide screws



STEP 2 Estimated Time: 15 minutes

Attach T spacers to outer gables with drawer slide screws.





STEP 3 Estimated Time: 10 minutes

Attach drawer glides to T-spacers on outer gables as shown in the photo

Position the Drawer Glides with:


- A) The wheel at the finished side
- B) The wheel on the unfinished bottom



STEP 4 Estimated Time: 5 minutes

Insert JRN nuts into the holes on each end of the inner gables.


The holes are drilled through. You can insert them from either side.




STEP 5 Estimated Time: 5 minutes

Insert JRN nuts into the holes on each end of the upper (B3) and lower (B4) stabilizers.

B3 Upper Stabilizers




B4 Lower Stabilizers




Identifying the upper and lower stabilizers

Upper Stabilizers



Lower Stabilizers


Side hole is close to the finished edge



STEP 6 Estimated Time: 10 minutes

Attach "T" spacers and drawer glides to Inner Gables

6a Attach "T" spacers to ONE side of each inner gable with drawer slide screws



6b Attach drawer glides to "T" spacers on inner gables.

Position the drawer glides with:

- A) The wheel at the finished edge
- B) The wheel on the bottom

IMPORTANT:


Before attaching the drawer glides, determine the TOP and BOTTOM of each inner gable.

A. Measure from each edge of the "T" Spacer to each unfinished edge.


B. The measurement that is approximately 4" will be the **BOTTOM**.

Check the position of the drawer glides carefully before you attach them to the inner gables.

CORRECT



INCORRECT





6c Repeat steps 6a & 6b for the 2nd side of the inner gables.



STEP 7 Estimated Time: 5 minutes

Using JCB connectors, and the Allen Key provided, attach each lower stabilizer (B4), one at a time, to both inner gables




Finished edge

IMPORTANT

Identifying the Lower Stabilizer


The screw hole is at the top, close to the finished edge

If you have any difficulty tightening the JCB connector, use a screwdriver to adjust the JRN nut to make sure the hole is facing the opening for the connector




STEP 8 Estimated Time: 5 minutes

Using JCB connectors, attach each upper stabilizer (B3), one at a time, to both inner gables.



STEP 8 Estimated Time: 10 minutes

Attach one outer gable (B1) to stabilizers with JCB connectors




STEP 9 Estimated Time: 5 minutes

- 9a** Spread the wooden slats out across the inner stabilizers
- 9b** Slide the slats into the wide spaces of the metal U-channel (B6) on one outer gable.




9b



STEP 10 Estimated Time: 10 minutes

Attach second outer gable to stabilizers with JCB connectors

- 10a** Secure the gable in place with connectors, but don't fully tighten
- 10b** Ensure the slats are set inside the u-channel and that they haven't pulled out of the first outer gable.
- 10c** Firmly tighten the connectors



Drawer Parts Identification

D1

Drawer Front (6)
black
cherry
espresso
maple
white

D2

Left Drawer Side (6)
Plywood

D3


Right Drawer Side (6)
Plywood

D4

Drawer Back (6)
unfinished


D5

Drawer Bottom (6)
unfinished




STEP 11 Estimated Time: 5 minutes PER DRAWER


11a Insert cams into drawer sides




Left Drawer Side




Right Drawer Side




11b Screw black twister dowels into drawer fronts




11c Attach drawer sides to drawer back with 1½" Hi Lo screws




11d Attach drawer front and tighten cams using a flat head screwdriver



11e Turn drawer upside down and slide drawer bottom into grooves





11f Secure the drawer bottom to the drawer back with nails





11g Insert the Drawer Bottom Stabilizer

Position the Stabilizer in the center of the drawer and insert it into the groove on the drawer front. This is the same groove that you inserted the drawer bottom into.

Then, tighten screw until it is flush





11h Attach drawer slides to left and right drawer sides using drawer slide screws



STEP 12 Estimated Time: 2 minutes

Insert drawers



Note: When drawers are installed correctly, you will not be able to remove them without first lifting up the drawer front.